

NICOLI™

Models/Modelos/Modèles

19868LF-▲

Series/Series/Seria

RP104027▲
Sprayer & Hose Assembly
Ensamblaje de pulverizador y manguera
Douchette et tuyau souple

RP60911
Clip
Presilla
Agrafe

RP62057


Hose Assembly & Clip
Ensamble de la Manguera y Presilla
Tuyau souple et agrafe



RP100956
Aerator & Wrench
Aerador y Llave
Aérateur et Clé




RP104018
Hose Weight Assembly
Ensamble de la Pesa de Acero
Masselotte en acier



RP28972
Nut
Tuerca
Écrou

RP47274▲
Escutcheon, Plate, Nuts and Gasket
Chapa, Placa, Tuercas y Empaque
Plaque de finition, Plaque, écrous et joint



RP104013
Wand Retainer & Replacement Kit
Soporte para el mango y piezas
de repuesto
Trousse de Rechange et pièce de
Retenue de Douchette

RP104009▲
Handle Assembly
Conjunto de manija
Montage de la manette

RP104012
Cartridge Assembly
Ensamble del la Válvula
Soupape


RP104029
Set Screw
Tornillo de Ajuste
Vis de Calage

RP26853
Allen Wrench
Llave
Clé

RP13938
O-Rings (2)
Anillos "O" (2)
Joints torique (2)



RP92714
Mounting Bracket Assembly, Nut
& Wrench
Ensamble del soporte de montaje,
la tuerca y la llave de tuercas
Fixation de montage, écrou et clé



▲Specify Finish / Especificque el Acabado / Précisez le Fini